



线圈数据 SOLENOID COIL DATA 08 series

Coil Must Be Installed With Letter Up  
 安装线圈时，字母必须朝上。

Unit=Millimeters




HIRSCHMANN



DOUBLE LEADS

订货代号 TO ORDER



- 1 功能**  
LC= 电磁线圈 Solenoid Coil

---

- 2 规格 Size**  
08=08 规格

---

- 3 形状 Shape**  
S= 方形 Square

- 4 电压 Voltage**

1=12 VDC	RED	LEAD	红线
2=24 VDC	BLUE	LEAD	蓝线
3=110VAC	BLACK	LEAD	黑线
4=220VAC	YELLOW	LEAD	黄线
5=10 VDC	GRAY	LEAD	灰线

- 5 线圈连接 Coil Connection**

D= Double Lead	双线
H= Hirschmann	三插