LSV2-08-3B

3-Way,2-Position, Spool-type Solenoid Valve

DESCRIPTION

A solenoid operated, 3-way, 2-position, spool-type cartridge valve.


OPERATION

When de-energized, the valve allows flow from ② to ① ,while blocking flow at ③ . When energized, the cartridge's spool shifts to allow flow from ② to ③ or from ③ to ② , while blocking flow at ① .

Operation of Manual Override Option

To override, push button in, twist counterclockwise 180° and release. In this position, valve will remain detented in the shifted condition. To return to normal operation, push button in, twist clockwise 180° and release. Override will be detented in this position.

SYMBOL






SPECIFICATIONS


Operating Pressure	207bar
Flow	See PERFORMANCE CHARACTERISTIC graph.
Internal Leakage	(per land)82cc/min max. at 207bar
Temperature	-40°F to +212°F(-40°C to +100°C)
Coil Duty Rating	Continuous from 85% to 115% of nominal voltage
Filtration	See page N-1
Fluids	Mineral-based fluids with viscosities of 7.4 to 420 cSt.
Cavity	08-3,See page M-1


Housing Material

6061-T6 aluminum alloy rated to 207bar, Steel & Ductile iron rated to 350bar




PRESSURE DROP VS.FLOW







TO ORDER



1 Function

LSV2=Solenoid Valve

2 Size

08=08 Size

- 3 Flow Path
 - **3B**=3-Way
- 4 Manual Override Options

Omit=None

M=Manual Override

5 Coil Voltage

1 =12	VDC
2 =24	VDC

- **3**=110 VAC 4=220 VAC
- 4=220 VAC 5=10 VDC
- 7=48 VDC
- 7=48 VDC 8=24 VAC
- 6 Coil Connector Type
 - D= Double Lead
 - S= Single Lead
 - H= Hirschmann
 - ER= Deutsch Connector(Water-proof Coil)
 - E= Single Stud
 - B= Double Spade

7 Port Size

Omit=None

- 4T=SAE 4
- 6T=SAE 6
- 2G=G 1/4
- **3G**=G 3/8
- See page K-2 for detail of housing
- XOther port sizes are available

INSTALLATION DIMENSIONS

Coil Must Be Installed With Letter Up

Unit=Millimeters

